

## คู่มือการใช้งานเครื่องชั่ง

**MODEL : LP7510-4-20mA**





5. กด  หน้าจอโชว์  กด  หน้าจอโชว์  กด  เพื่อเลือกค่าละเอียดตามต้องการ
6. กด  หน้าจอโชว์  กด  หน้าจอโชว์
7. กด  เพื่อเลื่อนหลัก กด  เพื่อเพิ่มตัวเลข ตั้งให้หน้าจอโชว์
8. กด  หน้าจอโชว์  กด  หน้าจอโชว์  กด  ให้หน้าจอโชว์  กด  เครื่องจะรันตัวเลขเสร็จ หน้าจอโชว์
9. กด  หน้าจอโชว์  กด  หน้าจอโชว์  กด  ให้หน้าจอโชว์
10. กด  หน้าจอโชว์  และตามด้วย
11. กด  เพื่อเลื่อนหลัก กด  เพื่อเพิ่มตัวเลข ตั้งให้หน้าจอโชว์
12. วางค้อนน้ำหนัก กด  หน้าจอโชว์  รันตัวเลขถอยหลังและตามด้วย
13. กด ON/OFF เพื่อออกจากฟังก์ชัน หน้าจอแสดงค่าน้ำหนักจริง

## Default parameter form

parameter	instruction	Default value
C01	Calibration unit	1
C02	decimal digits	0
C03	Division value	1
C04	Max capacity	10000
C05	Empty scales calibration	0
C06	Capacity calibration	0
C07	restore the default parameters	0
C08	Warning tone	1
C09	Automatic power off	0
C10	Power saving mode	0
C11	Hold function	0
C12	Animal weighing mode	0

C13	Upper limit warning	000000
C14	Lower limit warning	000000
C15	Inner code display	
C16	Date	
C17	Time	
C18	Serial interface data output method	0
C19	Serial interface Baud rate	3=9600
C20	Manual zero setting	2
C21	Initial zero setting	10
C22	Automatic zero tracking range	0.5
C23	Automatic zero tracking time	1
C24	Verload range	9
C25	Negative display range	10
C26	Standstill time	1
C27	Standstill range	2
C28	Dynamic filter	0
C29	Noisy filter	2
C30~C40	Reserved menu	